

1. styx-i

styx-i is an interface to connect your device via network with your PC.

- › Edit satellite & user lists from your PC.
- › Browse the directories of the connected USB memories to copy & delete files.

Enter the **styx-i** menu to operate the **styx-i** program from your PC.

2.1 styx-i program

Download the **styx-i** program from www.satnet.net.nz to your PC and unzip the file.

NOTE *Activate the **styx-i** menu of your device to operate the **styx-i** program from your PC.*

2.2 Channel editor

Connect	Open File - Connect to STB . Enter the IP address of the device.
Import data	<ul style="list-style-type: none">› Import the data directly from your device via the styx-i menu.› Export the data (chapter 5.4) to a USB memory and import/copy the file to your PC (open File - Import data).
Select channels	Press CTRL key to select a channel/channels in a list.
Edit sat lists	Right-click the mouse over a Satellite, transponder, channel to edit.
Edit user lists	<ul style="list-style-type: none">› Copy: To copy channels to a User list select the channels and click on the << icon.› Delete: To delete channels click on the X icon.
Move channel position	Select a channel in a list and press CTRL key and use the UP/DOWN keyboard keys to move the channel position.
Channel number display	Open Edit - Channel number display to change the displayed number of channels in a list and enter the channel numbers (min. 10 , max. 30 channels).
Export data	<ul style="list-style-type: none">› Open File - Update STB to export the data from the PC to your device via the styx-i menu.› Open File - Export data to export the file to a USB memory and import/copy the file to your device.

2.3 USBfile browser

Connect	Open Edit - File Brower . Enter the IP address of the device.
PC	Browse the directories of your PC.
Disk	Browse the directories of the USB memories connected to your device.
>> /<<	Copy files between your PC and USB memory.
Delete	Select a file and right click with the mouse to delete.